

# Cane Touch Apron - Installation Instructions

**Model LKAPRVRCHD for use on VRCHD / LVRCHD style coolers  
and Model HTAPRHVRHD for use on HVRHD style coolers**

## **Required Tools:**

To install this kit the following tools are required:

- Pinned Torx Head Driver (T25)
- Power Drill with 5/32" Drill Bit
- Hammer and Center Punch

## **Installation Procedure:**

1. Using the cane apron as a template use a center punch to mark hole locations on the underside of the HVRHD, VRCHD or LVRCHD coolers.
2. Drill 5/32" diameter holes at marked locations. (Center punch hole locations before drilling).  
**CAUTION:** When drilling holes, keep the drill bit away from any water lines in cooler. If the drill damages or punctures the tubing, expensive damage to the cooler could result.
3. Install cane touch apron to underside of cooler using the three (3) screws provided.

